



FEELPURE®

VOCILOCID

(SURFACE & ENVIRONMENT DISINFECTANT)



Voda Chemicals Pvt. Ltd.

Plot No. 171, Sector-53, Phase-5, HSIIDC Kundli, Distt. Sonapat (HR)- 131028 | www.vodachemicals.com



VOCILOCID

(SURFACE & ENVIRONMENT DISINFECTANT)

Composition :

Each 100 gm Contains :

1,6 Dihydroxy, 2-5 Dioxahexane	:	11.2g
Glutaraldehyde	:	5.0g
Benzalkonium Chloride IP	:	5.0g
Alkyl Urea Derivative	:	3.0g

ABOUT :

FEELPURE VOCILOCID is designed to clean and disinfect surfaces and environments. **FEELPURE VOCILOCID** Special has a very good cleansing property and a wide range of germicidal action, ensuring total disinfection of rooms and surfaces.

PRECAUTIONS :

- * Avoid contact with concentrated solution.
- * Keep away from children.
- * Do not mix with other disinfectant.
- * To reduce evaporation before and after application, close doors and windows and switch OFF ACs/Fans.

METHOD OF ACTION :

- Glutaraldehyde combines with 1,6 Dihydroxy,2-5 Dioxahexane in hydrolysis with water, to give excellent microbicidal activity.
- Only 30% is used, the rest is released, only when there is an addition of new contaminants.
- Benzalkonium Chloride and alkyl urea derivatives serve as surfactants.
- Separate corrosion inhibitors are added for protection of expensive surfaces.



✓ Bactericidal ✓ Virucidal
✓ Fungicidal ✓ Tuberculocidal ✓ Sporocidal

SPECTRUM OF ACTIVITY /

FEATURES :

Spectrum of Activity / Features :

- All fungi including Candida Albicans
- All gram positive bacteria including Staph. Aureus
- All gram negative bacteria including E.coli
- All mycobacteria
- All bacterial spores
- All fungal spores
- All viruses including HBV, HIV and HCV & Bird Flu
- All resistant bacteria including MRSA.
- Microorganisms do not show resistance to **FEELPURE VOCILOCID**.
- No irritation
- Compatibility with all types of surfaces
- Corrosion inhibition
- Prolonged residual effect
- Reduction in the replacement and maintenance cost of HEPA filters.

Voda Chemicals Pvt. Ltd.

Plot No. 171, Sector-53, Phase-5, HSIIDC Kundli, Distt. Sonapat (HR)- 131028 | www.vodachemicals.com



MODE OF USE ::

Critical Areas :

All ICU's, OT's, AKD, CCU, Oncoology, Cath Lab etc.

Non Critical Areas :

Wards, Corridors, OPS's, Clinics, Mobile Units,

Laboratories, Dental Clinics, etc.

Inbetween Cases for Emergency Disinfection.

MODE OF APPLICATION :

Mopping should be done by :

*** 3 Bucket system :**

Dirty mop should be first put in Bucket No. 1 (water) and then

rinsed in Bucket No. 2 (water) and then immersed in Bucket

No. 3 containing prepared solution of **FEELPURE VOCILOCID**

Mop liberally and keep wet for 5 to 10 minutes for optimum results.

*** Fumigation / Fogging** - 2% = 20ml in one litre of water

PRODUCT SPECIFICATION :

Colour	:	Transparent
Shelf life	:	2 Years
Re-use life	:	14 Days
pH	:	7.5 (Neutral)
Pack size	:	500 ML, 1000 ML, 5000 ML

GENERAL INSTRUCTIONS :

- To reduce evaporation before and after application close doors and windows and switch off ACs / Fans
- Disinfected surfaces must remain in contact i.e. wet with solution for 5, 10 or 20 minutes for optimum results.
- Avoid contact with concentrated solution.
- Do not mix with other disinfectants.
- Prepare fresh solution for better results.

Voda Chemicals Pvt. Ltd.

Plot No. 171, Sector-53, Phase-5, HSIIDC Kundli, Distt. Sonipat (HR)- 131028 | www.vodachemicals.com